

Dura-LITE Stair Instructions

1. Slide the head of your carriage bolts in the track provided on the top of the stairs.
2. Position the angle brackets to allow a 7" rise from the top step to the deck surface. Secure them with the 3/8" nylock nuts.
3. On the dock frame, slide a pair of 3/8" carriage bolts down the lower track to attach the angle brackets to the dock using the 3/8" nylock nuts.
4. 1 1/2" schedule 40 pipe can be used as leveling legs at the base of your stairs. Pipes can be driven or set on feet. Use a 1/4" allen wrench to tighten the set screws on the leveling legs.

