



Boarding Step Attachment



Use a 1/4" allen wrench to tighten the boarding step bracket onto a length of pipe (1.5" schedule 40) that will support your boarding step over the side of your 10' dock section..



Once the supporting pipe is secured with the set screws, slide the open socket over the dock leg. Repeat this step for the opposite end of your boarding step.



Pivot the two boarding step brackets so the boarding step sockets (built in) can be raised onto the supporting pipes and tightened at your desired level.



Tighten all remaining set screws and your boarding step is ready for use.

